
Installation Instructions

Spring-Type Spacers

1. Loosen bolts so that the clamp may be opened sufficiently to permit cable entry into the cable groove.
2. Align the clamps on the conductors. The spring should be straight and perpendicular to both conductors.
3. Tighten bolts with a socket wrench (thin wall recommended). Bolts of each clamp should be tightened in sequence for best results. Tighten one bolt to approximately 15 lb-ft (20N.m), then tighten the second bolt until torque control head shears off. First bolt should then be tightened until the torque control head shears off.