

### TYPE SWGRS

#### Swage Grease, 4 oz. bottle

Swage Grease is used to cut down on friction and contact between the Swage Dies and the Press Head and Die Block. This will ensure long life for dies, press head and die block.

#### Application

Swage Grease is applied generously to the back of each die and to the contacting surfaces of the die head and die block using the squirt bottle. After application, spread out grease with finger to ensure complete coverage is achieved between the surfaces. **NOTE:** Apply Swage Grease each time after cleaning tool.

#### Ordering Information

AFL NO.	DESCRIPTION
SWGRS-4	Swage Grease, 4 oz. bottle

