

For complete installation instructions and video, visit www.AFLglobal.com/APEX or use the QR code.



AFL APEX® POLE/WALL MOUNT KIT

Each kit comes with 2 brackets, hex bolt and lock washer.
(Bracket mounting hardware not supplied)

Ordering Information

DESCRIPTION	AFL NO.
Pole/wall Mount Kit	AX-BR30

Mounting Distance

APEX CLOSURE	DISTANCE
X-2	26 ¾" (68 cm)
X-2S	22 ½" (57.2 cm)



INSTALLATION OF BRACKET

Each bracket is universal top or bottom mount

1. Install lower bracket with Arrow facing up using appropriate fastening hardware for the application. **(Figure 1)**
2. Install upper bracket directly above the lower bracket in the same orientation, arrow up. Use the distance table above to define center to center distance of bracket mounting location.
3. Ensure Lock ring is oriented on Apex and will not interfere with mount insert access. **(Figure 2)**
4. Align Apex to install on brackets with mount insert closest to the pole.
5. Slide upper dome slot onto upper mount bracket. **(Figure 3)**



Figure 1




Figure 2



Figure 3

- Slide Apex base on top of lower mount bracket and allow lock ring to nestle in lower bracket and align mount insert with opening in lower bracket.
- Secure Apex with supplied hex bolt and lock washer through lower bracket into mount insert. (Figure 4)



Figure 4

