

ROGUE® OLTS Certifier Start Guide — Cloud-based reporting via aeRos®

1 Power On IB1

2 Launch App

Follow Steps
MAIN tester: 1 - 12
REMOTE tester: 1 - 3, 4.1, 7

3 Sign In

4 Tap Projects

4.1 Tap Remote Mode

5 Open YOUR Project

6 Open Fiber Group

7 Tap Start

8 Referencing

Follow screen prompts on MAIN and REMOTE to reference

9 Testing

Complete all tests in this Fiber Group

10 Tap Back

Once all fibers tested, tap **Back** button on your smart device to display Fiber Groups

11 Done!

Tap Results to see test data

12 Done!

Use aeRos reporting functionality to generate reports

ROGUE® OLTS Certifier Start Guide — Offline reporting via TRM® on PC

1 Power On iB1

2 Launch App

Follow Steps
MAIN tester: 1 - 12
REMOTE tester: 1 - 3, 4.1, 8

3 Opt Sign In

CANCEL

Work Offline

Tap either

4 Tap Projects

4.1 Tap Remote Mode

5 Create New Project

Create Project

6 Tap Start

Start

7 Referencing

If no valid reference data, follow screen prompts on MAIN and REMOTE to reference

Reference information missing.

Please perform referencing before running tests.

Cancel Ok

8 Tap Start

Start

9 Tap Back

Once all fibers tested, tap **Back** button on your iB1 to display Fiber Groups

10 Export Results

Share Results

Follow on-screen prompts

11 Prepare Reports in TRM® on PC

Fiber Summary

OLTS/OPM Results: 1
 OLTS Fiber Readings: 4
 OPM Fiber Readings: 0

Certification Results

Cabling Standard: ANSI/TIA-568.3-D2016, outside plant, OS2 singlemode.

Date of Test	Time	Fiber #	Loss (dB)	Length (m)	Pass	Headroom (dB)
			1310 nm	1550 nm		1310 nm
Nov 1, 2019	2:19 PM	1	0.92	1.02	Pass	1.79
			1.35	1.16		0.76
Nov 1, 2019	2:19 PM	2	0.88	0.83	Pass	1.29
			0.87	0.85		1.44
Nov 1, 2019	2:20 PM	3	0.76	0.84	Pass	1.35
			0.87	0.76		1.85
Nov 1, 2019	2:20 PM	4	0.30	0.33	Pass	1.81
			0.31	0.44		1.80
Nov 1, 2019	2:20 PM	5	0.37	0.60	Pass	1.75
			0.45	0.93		1.66
Nov 1, 2019	2:20 PM	6	0.37	0.51	Pass	1.54
			0.37	0.51		1.60

For details, see User's Guide @ www.AFLglobal.com